

**SK913 / SK914****SCREEN DOOR ROLLERS**

Remove screen door from frame and place on side. We suggest that you replace 1 roller at a time so as to keep a reference for reinstallation. Screen door rollers are fastened onto the corners of the screen door. Doors may operate with 2 or 4 rollers (top &/or bottom) the height of screen doors can be raised or lowered by adjusting the screws on the door corners.

**ROULEMENTS POUR PORTES MOUSTIQUAIRES**

Enlevez la porte moustiquaire du cadrage et placez-la sur le cote. Enlever et remplacez 1 roulement à la fois pour conserver un exemple en cas de difficulté.

Les roulements sont vissés dans les coins des portes moustiquaires. Les portes peuvent avoir 2 ou 4 roulements en haut et/ou en bas. La porte moustiquaire peut être levée ou basée en ajustant la vis dans le coin de la porte.