

CAN BE INSTALLED WITH OR WITHOUT THE OUTSIDE HANDLE

INSTRUCTIONS:

SK900

1. REMOVE OLD HANDLES AND STRIKE.
2. ATTACH INSIDE AND OUTSIDE HANDLES TO SCREEN DOOR FRAME AND SECURE WITH 2 MACHINE SCREWS.(8-32x1-1/4"FL.SK)
3. CLOSE SCREEN DOOR AND PLACE A MARK ON DOOR FRAME TO SHOW TOP OF HANDLE. INSTALL STRIKE (KEEPER) ON DOOR FRAME AND SECURE WITH SCREWS PROVIDED (8x1-1/4"FL.HD) MAKE SURE ALIGNEMENT OF HANDLE AND KEEPER IS CORRECT BEFORE TIGHTENING.
4. IF YOUR OLD SET HAD NO OUTSIDE HANDLE, OR IF THIS OUTSIDE HANDLE IS TO WIDE, INSTALL INSIDE HANDLE ONLY USING (8X1-1/4"FL.HD) WOOD SCREWS.

PEUT ETRE INSTALLE AVEC OU SANS POIGNEE EXTERIEURE

INSTRUCTIONS:

1. ENLEVER LES VIEILLES POIGNEES ET LA GACHE.
2. POSEZ LES POIGNEES INTERIEURE ET EXTERIEURE SUR LA PORTE MOUSTIQUAIRE ET LES FIXER AVEC 2 VIS MECHANIKES (8-32X1-1/4" TETE PLATE CARREE)
3. FERMEZ LA PORTE MOUSTIQUAIRE ET FAIRE UNE MARQUE SUR LE CADRAGE EN INDIQUANT LE HAUT DE LA POIGNEE INSTALLEZ LA GACHE SUR LE CADRAGE ET FIXER AVEC LES VIS FOURNIES (8X1-1/4" TETE PLATE) ASSUREZ VOUS QUE L'ALIGNEMENT DE LA POIGNEE AVEC LE GACHE EST EXACT AVANT DE VISSER COMPLETEMENT.
4. SI VOTRE VIEL ENSEMBLE N'AVAIT PAS DE POIGNEE EXTERIEURE SEULEMENT EN UTILISANT DES VIS A BOIT(8X1-1/4" TETE PLATE)